

# WINEGARD®

Model BW-1000

## SENSAR® Wind Deflector Kit INSTRUCTIONS

1. Completely lower Sensor antenna.
2. Place instruction sheet under front edge of antenna and align with drawing.
3. Peel plastic covering from deflector.
4. Drill two 1/8" dia. pilot holes where indicated.
5. Remove instruction sheet and apply silicone over pilot holes.
6. Place deflector on roof and secure to roof using the two (2) #10 x 1/2" slotted hex head screws provided.
7. Cover screw heads with silicone.

