



Wiring the Digital Receiver directly to the COAX input on the television.



The information and data contained herein is secret and shall not be disclosed, used or duplicated for any purpose whatsoever without the prior written permission of Winegard Company, 3000 Kirkwood St., Burlington Iowa 52601-2000. This legend shall be marked on any reproduction hereof in whole or in part. Receipt of this document shall be deemed to be an acceptance of the conditions specified herein.

Wiring two Digital Receivers using a Winegard video switch.
Digital Receiver connects to the television's Composite IN port.
This set up allows other Inputs from video switch to function.



The information and data contained herein is secret and shall not be disclosed, used or duplicated for any purpose whatsoever without the prior written permission of Winegard Company, 3000 Kirkwood St., Burlington Iowa 52601-2000. This legend shall be marked on any reproduction hereof in whole or in part. Receipt of this document shall be deemed to be an acceptance of the conditions specified herein.